TY PENNINGTON Style™



Owner's Manual

JEFFERSON 3PCS BISTRO SET

Product code: D71 M34631
UPC code: 769455 767585
Vendor Item: SC-K-101R/3

Date of purchase: _____/ _____/ _____

PARTS

Read through all the instructions before beginning assembly. Unpack and identify all the parts. Place them on a flat, non-abrasive surface. Assembly by two people is recommended.

ITEM	DESCRIPTION	QUANTITY
A	Rocker Top	2
B	T Shaped Connector	2
C	Center Post	2
D	Rocker Base	2
E	Seat cushion	2
F	Throw Pillow	2
G	Table Rim(16 Metal Washers and 16 Bolts attached)	1
H	Metal Leg	4
I	Tile	1



ACCESSORIES

Ja (1 spare)
M6 Bolt

Jb (4)
M8 Bolt



Jc (4)
M8 Nut

Jd (4)
M8 Locker

Je (4)
M8 Metal Washer

Jf (1)
Allen Wrench

Jg(1)
Open Hex Wrench



Jh (1)
M8 Hex Wrench

Ji (4 spares)
Tile Bumper



Jj (1)
Assembly
Instructions Sheet



ASSEMBLY INSTRUCTIONS

ROCKER ASSEMBLY

1



2

Jb x 2
M8 Bolt



Jc x 2
M8 Nut

Jd x 2
M8 Locker

Je x 2
M8 Metal Washer



- Don’t tighten completely.
- Repeat procedure for the other hole.
- Securely tighten all bolts and nuts.

3



- Repeat procedure for the other rocker.

TABLE ASSEMBLY

4

Ja x 16
M6 Bolt
(remove from table rim)

M6 Metal Washer x 16
(remove from table rim)



- Don't tighten completely.
- Repeat procedure for the other three legs.
- Securely tighten all bolts.

5



- Use tile bumper to adjust tabletop level if it needs.
- You can adjust the level by twisting knobs on the bottoms of the legs as desired.
- Your bistro set is now ready to use.

CARE INSTRUCTIONS

Wash with a mild solution of soap and water; rinse thoroughly. Dry completely. Do not use bleach or solvents.

Cover furniture with outdoor furniture covers when not in use.

sears

Please refer to part numbers when reordering

For questions or comments about product:
Call toll-free: 1-800-457-4652

Made in / Hech en CHINA
Distributed by Sears, Roebuck and Co., Hoffman Estates, IL 60179

See our extensive assortment of outdoor living products
on-line at www.sears.com and www.kmart.com